Vehicle Repair Protection

Good and Great plans cover you for small and big repairs, from a $500 radiator replacement to a $2,000 new transmission. Plans vary by number of components covered, price and free perks like Roadside Assistance.

uproar.car

ENGINE

	Great	Good
Cylinder Block	X	X
Cylinder Head Freeze Plug	X	X
Cylinder Head Gasket	X	X
Cylinder Head Cover	X	X
Cylinder Head Freeze Plug	X	X
Cylinder Head Bolt	X	X
Oil Pan	X	X
Oil Pan Drain Plug	X	X
Oil Pump Housing Assy	X	X
Upper Engine Mount	X	X
Lower Engine Mount	X	X
Timing Chain	X	X
Front Engine Mount	X	X
Rear Engine Mount	X	X
Upper Engine Mount Bracket	X	X
Lower Engine Mount Bracket	X	X
Upper Engine Mount Bracket	X	X
Oil Level Sensor	X	X
Oil Level Dipstick	X	X
Engine Mount Shock Dampener Assy	X	X
Camber Member	X	X
Engine Mount Support Brackets	X	X
Engine Cradle Crossmember	X	X
Engine Cradle Crossmember	X	X
Engine Mount Actuator Assy	X	X
Engine Mount Bracket	X	X
Anti-Sensor Ring	X	X
Rear Mount Bracket	X	X
Main Bearing	X	X
Main Bearings	X	X
Piston Rings	X	X
Piston & Pin Set	X	X
Connecting Rods & Cap Set	X	X
Engine Timing Cover	X	X
Engine Timing Belt	X	X
Balance Shaft Set	X	X
Serpentine Belt Tensioner Pulley	X	X
Serpentine Belt Idler Pulley	X	X
Serpentine Belt Tensioner Spring	X	X
Piston Pin	X	X
Piston Oil Jet	X	X
Crankshaft Thrust Washers	X	X
Crankshaft Bearing Set	X	X
Crankshaft Pulley	X	X
Rear Main Seal	X	X
Harmonic Balancer Unit	X	X
Camshafts	X	X
Camshaft Oil Seals	X	X
Crankshaft Front Oil Seal	X	X
Crankshaft Rear Oil Seal	X	X
Valve Cover Gasket	X	X
Converter Rod Bushing	X	X
Fuel Pump Drive Gear	X	X
Timing Chain	X	X
Timing Chain Set	X	X
Camshaft Gear	X	X
Camshaft Timing Sprocket Assy	X	X
Valve Lifter	X	X
Front Cover Gasket	X	X
Timing Chain Tensioner	X	X
Timing Chain Dirt Jet	X	X
Timing Chain Guide Rail	X	X
Balancer Shaft Tensioner	X	X
Oil Pump Chain Guide	X	X
Oil Pump Chain Tensioner	X	X
Intake Valves	X	X
Exhaust Valves	X	X
Valve Spring Spring Assy	X	X
Coolant Inlet Pipe	X	X
Valve Guides	X	X
Valve Seals	X	X
Valve Springs	X	X
Valve Lifter	X	X
Valve Pivots	X	X

	Great	Good
Electric Water Pump Relay	X	X
Electric Water Pump Assembly	X	X
Electric Misc Wiring Harness	X	X
Auto Trans Fluid Cooler Assy	X	X
Auto Trans Fluid Cooler Valves	X	X
Radiator Air Flow Guides	X	X
Radiator Fan Motor	X	X
Radiator Shutter Controller	X	X
Radiator Shutter Wiring Harness	X	X
Oil Pressure Sensor	X	X
Oil Pressure Switch	X	X
FUEL & AIR INDUCTION SYSTEM		
Fuel Injection Assembly	X	X
Throttle Body	X	X
Purge Control Valve Assembly	X	X
Fuel Injector Seal Set	X	X
Purge Control Solenoid	X	X
Vacuum Cut Bypass Valve	X	X
Pressure / Evap Purge	X	X
Evap Valve Assembly	X	X
Evap Canister	X	X
Vapor Canister Assy	X	X
Vapor Canister Assy	X	X
Fuel Injector Set	X	X
Purge Cut Valve	X	X
Fuel Injector Solenoid	X	X
Valve Control Solenoid Valve	X	X
Boost Cntrl Solenoid Valve	X	X
Fuel Injector Rail	X	X
Idle Compensator	X	X
Air Injection Pump	X	X
Fuel Rail Groove Kit	X	X
Air Cleaner Asm Valve	X	X
Air Cleaner Housing	X	X
Idle Compensator Tube	X	X
Air Cleaner Insulator	X	X
Air Filter	X	X
Air Intake Boot Clamp	X	X
Air Temp Sensor	X	X
Air Temp Sensor Relief Valve	X	X
Fuel Injector Set	X	X
Fuel Injectors	X	X
Fuel Injector Seal Unit	X	X
Fuel Pump Relief Kit	X	X
Electric Fuel Pump	X	X
Fuel Pump Assembly	X	X
Fuel Pump Gasket	X	X
Fuel Pump Module	X	X
Fuel Tank	X	X
Tube Assy Filler	X	X
Fuel Filler Cap	X	X
Fuel Filler Door	X	X
Fuel Vented Protector	X	X
Fuel Tank Strap Set	X	X
Fuel Tank Securing Straps	X	X
Fuel Check Valve	X	X
Fuel Tank Pressure Sensor	X	X
Emissions Vapor Hose	X	X
Emissions Vapor Vent Hose	X	X
Fuel Breather Tube	X	X
Fuel System O-rings	X	X
Fuel Line	X	X
Fuel Pipe Breather Valve	X	X
Evaporator Shut - Off Valve	X	X
Fuel Line Clamp	X	X
Fuel Idle Up Valve Assy	X	X
Fuel Outlet Tube	X	X
Fuel Return Tube	X	X
Fuel Return Tube	X	X
Front Fuel Tube	X	X
Auto - Adjusting Accel Pedal	X	X
Accelerator Cable	X	X
Accelerator Bracket	X	X
Pedal Stopper Bracket	X	X
Accelerator Wire	X	X
Accelerator Pedal	X	X
Throttle Position Sensor	X	X
Drive By Wire Throttle Assembly	X	X

	Great	Good
Fuel Temp Sensor	X	X
Fuel Temperature Sensor	X	X
Fuel Dampener	X	X
Air Fuel Ratio Sensors	X	X
Ecm Main Relay	X	X
Dropping Resistor	X	X
Crankshaft Position Sensors	X	X
Camshaft Position Sensors	X	X
Variable Timing Control Sensors	X	X
Knock Control Sensors	X	X
Evap Control Purg Press Sensor	X	X
Fuel Cut Off Switch	X	X
Throttle Actuator	X	X
Throttle Body Assembly	X	X
Throttle Body Gasket	X	X
TURBOCHARGER & SUPERCHARGER		
Air Intake Boot - Breather	X	X
Intake Manifold	X	X
Exhaust Manifold	X	X
Exhaust Manifold Gasket	X	X
Exhaust Manifold Studs	X	X
Manifold Tube Assembly	X	X
Manifold Collection	X	X
Intake Manifold Gasket	X	X
Lower Collector Gasket	X	X
Intake Manifold Gasket	X	X
Intake Manifold Runner	X	X
Intake Collector Tube - Plenum	X	X
Turbocharger Assembly	X	X
Turbocharger Gasket Kit	X	X
Turbo Oil Drain Tube	X	X
Turbocharger Wastegate	X	X
Turbocharger Actuators	X	X
Turbocharger Solenoid	X	X
Supercharger Assembly	X	X
Supercharger Gasket Kit	X	X
Supercharger Rotors	X	X
Supercharger Press Sensors	X	X
Supercharger Noise Cone Assy	X	X
Supercharger Temperature Sensor	X	X
Supercharger Drive Belt	X	X
Absolute Pressure Sensor	X	X
Boost Control Solenoid	X	X
ENGINE ELECTRICAL		
Alternator Bracket	X	X
Alternator Battery Bar	X	X
Drive Belt Tensioner	X	X
Alternator Pulley	X	X
Thermo Element Assembly	X	X
Transistor Ignition Unit	X	X
Ignition Coil	X	X
Distributor Shaft	X	X
Distributor Rotor	X	X
Distributor Pickup Assembly	X	X
Distributor Pinion	X	X
Distributor Cam	X	X
Distributor Rotor Head	X	X
Distributor Magnets	X	X
Distributor Housing	X	X
Distributor Cap	X	X
Stator	X	X
Ignition Control Protector	X	X
Ignition Coil Pwr Transistor	X	X
Distributor Shaft Hold Down	X	X
Ignition Coil	X	X
Ignition Coil Protector	X	X
Alternator	X	X
Alternator Wiring Harness	X	X
Alternator Rotor	X	X
Alternator Bearing	X	X
Alternator Brush & Holder	X	X
Alternator Pulley	X	X
Alternator Bracket	X	X
Voltage Regulator	X	X
Diode Set	X	X
Starter Motor Assy	X	X
Starter Reluctor	X	X

	Great	Good
Armature	X	X
Starter Clutch Pinion	X	X
Starter Reduction Gear	X	X
Starter Solenoid	X	X
Brushes	X	X
Starter Motor	X	X
Starter Hold Cntrl Unit (Ecu)	X	X
Engine Wiring Harness	X	X
Power Distribution Center	X	X
Fuse Box Cover Plate	X	X
Fuses & Relays	X	X
FUEL INJECTION		
Fuel Injection Pump	X	X
Pressure Reg & Control Solenoid Valve Assy	X	X
Power Valve Actuator	X	X
Fuel Injection Nozzle	X	X
Vacuum Control Actuator	X	X
Altitude Switch	X	X
Start Pot	X	X
Idle Unit	X	X
Throttle Chamber	X	X
Accelerator Sensor	X	X
Vacuum Tank	X	X
Vacuum Pump	X	X
Control Unit - Ej	X	X
Throttle Valve Switch	X	X
Air Flow Sensor	X	X
Air Temperature Sensor	X	X
Cylinder Head Temp Sensor	X	X
Knock Sensor	X	X
Pressure Reg & Control Solenoid Valve Assy	X	X
Air Flow Meter	X	X
Air Flow Meter Bracket	X	X
Vacuum Control Valve	X	X
Vacuum Switch	X	X
EMISSION CONTROLS		
Pcv Valve	X	X
Pcv Hose	X	X
Egr Control Valve	X	X
Egr Passage	X	X
Egr Temperature	X	X
Exhaust Temp Sensor	X	X
Bpt Valve	X	X
Air Pump Case	X	X
Pump Mounting Bracket	X	X
A/I Tube	X	X
Air Injection Pipe	X	X
Valve Assy - Air Cut Solenoid	X	X
Air Injection Valve	X	X
A/I Valve	X	X
Air Injection Valve	X	X
A/I Hose	X	X
Ej Hose	X	X
Connector - Hose, 3-way	X	X
Connector - Hose	X	X
A/I Box	X	X
Service Port - Evap	X	X
Evap Control Valve	X	X
Vapor Control Valve	X	X
Egr Solenoid Valve	X	X
Egr Temperature Solenoid	X	X
Spark Delay Valve	X	X
Valve Assy - Vacuum Switch	X	X
Variable Intake Vacuum Tank Assy	X	X
Ck Switch - Canister Vac Cntrl	X	X
Ck Switch - Vacuum Cntrl	X	X
Ck Sensor	X	X
Rear Oxygen O2 Sensor	X	X
Front Oxygen O2 Sensor	X	X
Crank Angle Sensor	X	X
Crank Position Sensor - Ring Gear	X	X
Knock Sensor	X	X
Air Control Valve	X	X
Air Control Solenoid	X	X
Egr Reservoir Tank	X	X

DRIVE AXLE

	Great	Good
Differential Lock Switch	X	X
Axle Shaft Switch	X	X
Differential Lock Unit	X	X
Axle Shaft	X	X
Front Propeller Shaft	X	X
Journal Assy	X	X
Drive Line Center Bearing Mount	X	X
Drive Line Center Bearing Assy	X	X
Drive Line Center Bearing Mount	X	X
Drive Line Center Brg Insulator	X	X
Axle Shaft Seal	X	X
Diff Drive Gear Bolts	X	X
Rear Pinion Bearing	X	X
Rear Pinion Bearing Spacer	X	X
Pinion Bearer Spacer	X	X

	Great	Good
Pilot Bearing Spacer	X	X
Drive Pinion Oil Seal	X	X
Companion Flange	X	X
Axle Shaft	X	X
Side Flange Asm	X	X
Differential Side Shaft Assy	X	X
Axle Shaft	X	X
Differential Side Bearing	X	X
Differential Side Bearing Spacer	X	X
Ring & Pinion Gear Set	X	X
Rear Axle Shaft Assembly	X	X
Rear Cover Gasket	X	X
Differential Oil Cooler (Factory)	X	X
Axle Shaft Seal	X	X
Differential Side Bearing	X	X
Differential Side Bearing Spacer	X	X
Differential Side Bearing O-ring Seal	X	X
Pax Disc	X	X

	Great	Good
Rear Cover	X	X
Differential Housing Breather	X	X
Differential Housing Breather Asm	X	X
Axle Shaft	X	X
Drain Plug Washer / Gskt	X	X
Ltd Slip Differential Assy	X	X
Differential Case	X	X
Side Gears	X	X
Side Gear Thrust Washer	X	X
Pinion Mate	X	X
Pinion Mate Thrust Washer	X	X
Differential Pinion	X	X
Pinion Shaft Lock Pin	X	X
Pinion Shaft Lock Pin 4wd	X	X
Ltd Slip Clutch Kit	X	X
Ltd Slip Pressure Ring	X	X

	Great	Good
Ltd Slip Friction Plate	X	X
Ltd Slip Friction Disc	X	X
Side Bearings	X	X
Side Bearing Cap	X	X
Drive Pinion	X	X
Ring & Pinion 4wd	X	X
Front Pinion Bearing 4wd	X	X
Ring & Pinion Bearing 4wd	X	X
Front Pinion Bearing Spacer 4wd	X	X
Front Pinion Oil Seal 4wd	X	X
Companion Flange 4wd	X	X
Front Axle Shaft Assy	X	X
Side Gears 4wd	X	X
Side Gears Thrust Washers	X	X
Ltd Slip Pinion 4wd	X	X
Pinion Mate Thrust Washer	X	X

	Great	Good
Pinion Mate Shaft 4wd	X	X
Side Bearings 4wd	X	X
Drive Gear Bolts 4wd	X	X
Drive Gear 4wd	X	X
Front Axle Clutch Disks	X	X
Post-shock Clutch Housing	X	X
Post-shock Clutch	X	X
Rear Cover Gasket 4wd	X	X
Rear Cover 4wd	X	X
Front Axle Housing	X	X
4wd Pnt Driveshaft Dr Joint	X	X
4wd Pnt Driveshaft Dr Joint	X	X
4wd Driveshaft Slip Yoke	X	X

TRANSMISSION

	Great	Good
CLUTCH, TRANSMISSION, TRANSAXLE & TRANSFER CASE		
Mount - Transmission, Front	X	X
Mount - Transmission, Side	X	X
Mount - Transmission, Rear	X	X
Mount - Transmission, Lower	X	X
Mount - Transfer Case	X	X
Flywheel Assy	X	X
Flywheel Ring Gear	X	X
Clutch Disc	X	X
Clutch Pilot Bearing	X	X
Alt Oil Cooler (External)	X	X
Auto Trans Oil Cooler Lines	X	X
Alt Cooler Bypass Valve	X	X
Dropping Resistor	X	X
Ecu Cancel / Power Switch	X	X
Shift Pattern Select Switch	X	X
Shift Lock Relay	X	X
Shift Lock Relay	X	X
Transfer Relay	X	X
Clutch Switch	X	X
Clutch Interlock Switch	X	X
Kickdown Switch	X	X
Alt Steering Column Shift Switch	X	X
Alt Steering Switch	X	X
Interlock Control Unit	X	X
Transfer Case Motor	X	X
Transfer Motor Assy	X	X
Inverter (Fuji)	X	X
Converter Assy	X	X
Valve Body Wiring Harness	X	X
Auto Trans Solenoid Service	X	X
Electr Power Clutch Assy	X	X
Brush Holder Assy	X	X
Auto Trans Solenoid Housing	X	X
Clutch Release Rod Bushing	X	X
Clutch Withdrawal Lever	X	X
Clutch Release Lever Shaft	X	X
Dust Cover	X	X
Hyd. Clutch Damper	X	X
Clutch Fork	X	X
Clutch Master Cylinder	X	X
Clutch Operating Cylinder	X	X
Release Clutch	X	X
Push Rod	X	X
Clutch Release	X	X
Push Rod	X	X
Hyd. Check Valve Assy	X	X
Clutch Tube Assy	X	X
Clutch Tube / Line Metal	X	X
Clutch Hydraulic Hose	X	X
Clutch Line Bracket	X	X
Air Bleed Connector	X	X
Clutch Operating Cable	X	X
Clutch Release Cable	X	X
Automatic Trans Assy Housing	X	X
Automatic Transaxle Purse Generator	X	X
Alt Control Unit	X	X
E/D Indicator Switch	X	X
Shift Indicator	X	X
Vacuum Modulator Tube	X	X
Hyd. Clutch Damper	X	X
Clutch Fork	X	X
Primary Pully Assy (Cvt)	X	X
Secondary Pulley Assy (Cvt)	X	X
Drive Belt (Cvt)	X	X
Oil Cooler Valve (Cvt)	X	X
Clutch Housing (Cvt)	X	X
Converter Housing (Cvt)	X	X
Converter Housing Gasket	X	X
Transmission Oil Pump	X	X
O/D Case oil Spl	X	X
Lubrication Pipe (Cvt)	X	X
Lubrication Valve (Cvt)	X	X
Control Solenoid Valve	X	X
Rear Extension Gasket	X	X
Rear Extension Housing	X	X
Oil Pump	X	X
Oil Pump Sub Housing	X	X
Oil Pump Gear	X	X
Oil Pump Housing Seal	X	X
Oil Pump Rotor Set	X	X
Oil Pump Shaft Assy (Cvt)	X	X
Internal Locknuts (Cvt)	X	X
Oil Pump Gasket	X	X

	Great	Good
Shift Connection Rod (Cvt)	X	X
Parking Pawl	X	X
Park Lock Pawl	X	X
Park Control Assy	X	X
Alp Switch	X	X
Neutral Switch	X	X
Reverse Lamp Switch	X	X
Trap/ Neutral Switch	X	X
Neutral Switch - 4wd	X	X
Neutral Switch	X	X
Diff Lock Actuator Switch	X	X
Diff Lock Actuator Motor	X	X
Oil Catch Cooler Line	X	X
Switch Bracket	X	X
Sensor Assy - Position	X	X
Magnet Assy - Position	X	X
Drain Plug	X	X
Drain Plug Washer / Gskt	X	X
Oil Strainer	X	X
Neutral Position Switch	X	X
Oil Guide / Cutter	X	X
Oil Baffle	X	X
Thermostatic Magnet	X	X
Transmission Front Cover	X	X
Front Cover Gasket	X	X
Front Cover Oil Head Seal	X	X
Case Cover	X	X
Rear Extension Assy	X	X
Differential Unit Breather	X	X
Rear Extension Gasket	X	X
Rear Extension Bearing	X	X
Yoke Sleeve Dust Cover	X	X
Rear Extension Seal	X	X
Adapter Plate	X	X
Bearing Retainer	X	X
Extension Housing	X	X
Extension Lower Cover Gasket	X	X
Baffle Plate	X	X
Oil Pump Housing Assy	X	X
Pilot Bearing	X	X
Counter Shaft Rr Thrust Washer Gear, 1st Speed	X	X
Countershaft Nut	X	X
Main Shaft	X	X
Main Shaft Lock Nut	X	X
Reverse Main Gear	X	X
Reverse Main Gear Thrust Washer	X	X
Main Gear 2nd Speed	X	X
3rd Counter Gear Assy	X	X
3rd Main Gear	X	X
Main Gear Nut	X	X
4th Counter Gear Assy	X	X
Countershaft	X	X
Main Gear 4th Speed	X	X
4th Gear Hub Sleeve	X	X
4th Gear Input Shaft	X	X
Main Gear Thrust Washer	X	X
Main Shaft Bearing	X	X
Main Shaft Bearing	X	X
Counting Gear Needle Bearing	X	X
Reverse Idler Gear Assy (Cvt)	X	X
Reverse Idler Gear	X	X
Reverse Idler Shaft	X	X
Reverse Idler Bearing	X	X
Reverse Idler Gear Nut	X	X
Hub & Sleeve Set	X	X
Input Gear (5th)	X	X
Main Shaft Rear Cam Assy (Cvt)	X	X
Main Shaft (5th)	X	X
Main Gear (5th)	X	X
5th Main Gear Nut	X	X
2nd Main Shaft Gear Assy	X	X
Synchronizer	X	X
Synchronizer Hub	X	X
Synchronizer Coupling Sleeve	X	X
Synchronizer Ring	X	X
Speed Ring Retainer	X	X
Baulk Ring	X	X
Speed Ring Retainer	X	X
Pinion Gear	X	X
Insert	X	X
Reverse Baulk Ring	X	X
Synchronizer Assy	X	X
Baulk Ring (1-2)	X	X

	Great	Good
Baulk Ring (2nd)	X	X
Baulk Ring (3rd)	X	X
Baulk Ring (4th)	X	X
Baulk Ring (5th)	X	X
Synchro Ring Set (5th)	X	X
Speed Master Drive Gear	X	X
Speedometer Driven Gear	X	X
Speedometer Pinion	X	X
Speedometer Check Ball & Spring	X	X
Shift Fork Set	X	X
Shift Fork	X	X
Fork Shaft Bushing	X	X
Fork Shaft	X	X
Fork Rod Bushing	X	X
Fork Rod Clips	X	X
Ring Stopper	X	X
Rod Bracket	X	X
Fork Rod	X	X
Interlock Plunger	X	X
Shift Fork Assy (Cvt)	X	X
Shift Fork Shaft	X	X
Check Ball	X	X
Check Ball Springs	X	X
Shift Fork Shaft Seals	X	X
Check Ball Plug	X	X
Control Lever Assy	X	X
Control Lever Shaft	X	X
O-ring	X	X
Lever Shaft Control Levers	X	X
Lever Control Shaft	X	X
Select Check Spring	X	X
Select Check Ball	X	X
Detent Return Spring	X	X
Control Rod Shaft Oil Seal	X	X
Control Rod	X	X
Control Rod Boot	X	X
Control Lever Socket (Ball)	X	X
Control Lever Ball Stud	X	X
Shift Knob Oil Switch	X	X
Control Lever Housing Assy	X	X
Shift Lever Assy	X	X
Pilot Bearing Spacer	X	X
Striking Rod Slide	X	X
Striking Rod Bushings	X	X
Striking Rod Lever	X	X
Striking Rod Spring	X	X
Main Shaft Lock Nut	X	X
Striking Rod Pin	X	X
Striking Rod Assy O-ring	X	X
Transfer Case Mount Bracket	X	X
Transfer Case Mounting	X	X
Transfer Case Rear Housing	X	X
Transfer Case Half Seal	X	X
Transfer Case Rear Bearing	X	X
Transfer Case Output Seals	X	X
Transfer Case Main Gear	X	X
Transfer Case Main Shaft	X	X
Transfer Case Idler Gear	X	X
Ball Bearing Main Gear	X	X
Front Drive Chain	X	X
Front Output Shaft	X	X
Countershaft	X	X
Counter Gear	X	X
Counter Gear	X	X
Tapered Gear	X	X
Counter Gear Bearing	X	X
Front Drive Sprocket Sleeve	X	X
Main Shaft Bearing Spacer	X	X
Low Speed Gear	X	X
Front Drive Sprocket	X	X
Drive Shaft Bearing	X	X
Drive Shaft	X	X
Needle Bearing	X	X

	Great	Good
Pressure Line Assy	X	X
Hose I Tube - Gear To Pump	X	X
Hose I Line - Pump To Gear	X	X
F.T.Return Hose	X	X
Electric Steering Motor	X	X
Power Steering Control Vlv	X	X
Power Steering Oil Switch	X	X
Air Control Valve	X	X
Air Control Solenoid	X	X
Power Steering Pump Assy	X	X
Rear Axle Ball Joint Assy	X	X
Pump Reservoir Assy	X	X
Rear P / S Rack Assy	X	X
Rear P / S Rack Seal	X	X
Position Sensor Assy - Main	X	X
Position Sensor Assy - Sub	X	X
Pressure Rear Tube / Hose Set	X	X

SUSPENSION

	Great	Good
Select Switch	X	X
Suspension Control Unit	X	X
Suspension Actuator	X	X
Sensor Assy - Vehicle Angle	X	X
Rear Axle Shaft	X	X
Rear Axle Shaft Nut	X	X
Rear Axle Shaft Seal	X	X
Rear Axle Shaft Yoke	X	X
Rear Drive Shaft	X	X
Rear Drive Shaft	X	X
Drive Shaft Boots	X	X
Slide Joint Housing	X	X
Slide Joint Kit	X	X
Knuckle Spindle (Fwd & Rwd)	X	X
King Pin	X	X
King Pin Bearing	X	X
Steering Stopper Bolt	X	X
Steering Arm	X	X
Knuckle Arm	X	X
Drive Shaft Boot	X	X
Drive Shaft Set	X	X
Lower Ball Joint	X	X
Lower Ball Joint Seal	X	X
Drive Shaft Boot Kit	X	X
Drive Shaft Bearing 4wd	X	X
Front Wheel Bearing (Fwd)	X	X
Front Hub Nut	X	X
Front Bearing Dust Seal	X	X

	Great	Good
Strut Mounts	X	X
Gland Packing	X	X
Strut Bearing	X	X
Strut Bushing	X	X
Front Rebound Stoppers	X	X
Front Coil Spring Set	X	X
Front Suspension Member	X	X
Front Strut Assy	X	X
Link Spindle	X	X
Front Crossbar Assy	X	X
Front Suspension Arm	X	X
Compressor Bracket	X	X
Tension Rod	X	X
Front Suspension Rod Assy	X	X
Tension Rod Bushing	X	X
Transverse Link Support	X	X
Lower Link Bushing	X	X
Upper Link Bushing	X	X
Lower Link Assy	X	X
Upper Trans/verse Link	X	X
Lower Link Spindle	X	X
Steering Knuckle Extension	X	X
Front Stabilizer	X	X
Front Stab Bracket & Bushing	X	X

	Great	Good
Connecting Rod Pivots	X	X
Upper Link Assy	X	X
Lower Link Assy	X	X
Lower Link Bushings	X	X
Rear Spring	X	X
Rear Rebound Stoppers	X	X
Rear Spring Seat Rubber	X	X
Rear Spring Shackle Pin	X	X
Rear Spring Shackle	X	X
Rear Spring Bushing	X	X
Upper Link Bushing	X	X
Spring Location Plate	X	X
Rear Suspension Lower Link Assy	X	X
Radius Rod Link	X	X
Front Lower Link Assy	X	X
Rear Upper Suspension Arm	X	X
Control Rod	X	X
Control Rod Bushings	X	X
Rear Axle Beam	X	X
Panhard Rod Mount	X	X
Panhard Rod Bushing	X	X
Radius Rod Bushing	X	X
Panhard Rod Assy	X	X
Rear Suspension Arm	X	X
Leaf Springs	X	X
Rear Spring Pin	X	X
Front Stabilizer Bushing	X	X
Spring Lock Plate	X	X

	Great	Good
Bounce Bumpers	X	X
Spring Leaf Bushings	X	X
Spring Pad Leaf	X	X
Spring Pad Coil	X	X
Lower Link Bracket	X	X
Spring Seat Lower	X	X
Upper Link Bracket	X	X
Spring Seat Upper	X	X
Rear Suspension Arm Bushing	X	X
Diff Mounting Insulator	X	X
Rear Suspension Arm Bracket	X	X
Torque Arm Bracket	X	X
Torque Arm Bushing	X	X
Differential Mounting Bracket	X	X
Differential Mounting Bushing	X	X
Differential Mounting Insulator	X	X
Stabilizer Bracket	X	X
Stabilizer Bar (Rod)	X	X
Torsion Beam - Rear Axle	X	X
Rear Axle Housing	X	X
Rear Anchor Arm	X	X
Parallel Rod Bolt	X	X
Parallel Rod Bushing	X	X
Rear Stabilizer	X	X
Bracket - Rr Stabilizer	X	X
Rear Stabilizer Bushing	X	X
Mounting Bracket Bushing	X	X

BRAKES

	Great	Good
Tcs Switch Assy	X	X
Brake Booster	X	X
Abs Relay Relay	X	X
Abs Control Unit Assy	X	X
Tire Pressure Monitor Relay	X	X
Stop Lamp Switch	X	X
Parking Brake Switch	X	X
Parking Brake Switch	X	X
Ratchet Nut	X	X
Parking Brake System	X	X
Parking Brake Relay	X	X
Hand Brake Bracket	X	X
Hand Brake Cable	X	X
Hand Brake Assy	X	X
Hand Brake Control Lever Yoke	X	X
Hand Brake Lever	X	X
Check Pin Hand Brake	X	X
Brake Pedal	X	X
Center Lever Brake	X	X
Adjustor Nut	X	X
Rear Cable	X	X

	Great	Good
Cross Cable	X	X
Rear Cable Rod	X	X
Park Brake Cable Protector	X	X
Camber Shaft	X	X
Equalizer	X	X
Hanger Strap/ Temp Arm	X	X
Rear Brake Backing Board	X	X
Return Spring	X	X
Rear Cable Adjustor	X	X
Rear Cable	X	X
Rear Cable	X	X
Tire Pressure Sensor Control Unit	X	X
Tire Pressure Sensor	X	X
Tire Pressure Antenna Cable	X	X
Antenna - Tire Pressure	X	X
Caliper Piston	X	X
Caliper Pin Bolt Down Pin	X	X
Caliper Pivot Pin	X	X
Anti-squeale Spring	X	X
Caliper Piston Cap	X	X

	Great	Good
Front Caliper	X	X
Front Brake Pad Set	X	X
Front Baffle Plate	X	X
Caliper Pin Shims	X	X
Rear Caliper	X	X
Backing Plates	X	X
Rear Caliper	X	X
Hold Down Pin	X	X
Extension Link	X	X
Rear Brake Pad	X	X
Rear Brake Pad Lower Yoke	X	X
Rear Brake Return Spring	X	X
Rear Caliper	X	X
Rear Wheel Cylinder	X	X
Lever Assy	X	X
Rear Brake Shoe	X	X
Push Rod Set	X	X
Anchor - Parking Brake	X	X
Adjuster Assy	X	X
Master Cylinder	X	X
Brake Booster Valve	X	X

	Great	Good
Oil Reservoir Cap	X	X
Reservoir Seal	X	X
Level Indicator	X	X
Reservoir	X	X
Snap Ring	X	X
Fluid Reservoir	X	X
Master Cylinder	X	X
Hard Reservoir Line	X	X
Front Brake Line	X	X
Brake Hose	X	X
Abs Line Connectors	X	X
Brake Pipes	X	X
Rear Brake Brake Line	X	X
Rear Brake Hose	X	X
Load Sensing Valve	X	X
Proportioning Valve	X	X
Auto Adjusting Brake Pedal	X	X
Brake Pedal Position Sensor	X	X
Pedal Stopper	X	X
Brake Pedal	X	X
Brake Pedal Bushing	X	X

	Great	Good
Brake Fulcrum Shaft	X	X
Brake Pedal Sleeve	X	X
Brake Booster	X	X
Brake Booster Spacer	X	X
Brake Pressure Sensor Assy	X	X
Brake Booster Line/ Hose	X	X
Brake Booster Vacuum	X	X
Brake Booster Diaphragm	X	X
Check Valve	X	X
Brake Booster Check	X	X
Abs Line Connectors	X	X
Abs Brake Control Module	X	X
Abs Actuator	X	X
Abs Modulator	X	X
Abs Control Unit and Assy	X	X
Abs Brake Capacitor	X	X
Abs Sensor Assy Front	X	X
Abs Sensor Assy Rear	X	X

ELECTRICAL

	Great	Good
Ascd-Cc Cancel Switch	X	X
Cruise Control Module	X	X
Horn Relay	X	X
Engine Hi-horn	X	X
Instrument Harness	X	X
Horn Switch	X	X
Horn	X	X
Chassis Harness	X	X
Console Harness	X	X
Engine Sub - Harness	X	X
Engine Room Harness	X	X
Dash Harness	X	X
Air Bag Harness	X	X
Rear Window Defroster Relay	X	X
Rear Window Defroster Relay	X	X
Defroster Wing	X	X
Defroster Grid	X	X
Volt Meter	X	X
Digital Temperature Meter Assy	X	X
Speedometer	X	X
Speedometer Cable	X	X
Tachometer	X	X
Fuel Gauge	X	X
Oil Pressure Gauge	X	X
Water Temp Gauge	X	X
Coolant Temp Gauge	X	X
Instr Gauge Circuit Board	X	X
Instr Cluster Housing	X	X
Security Indicator Lamp	X	X
Dash Printed Circuit Board	X	X
Speedometer Gear	X	X
Speedometer Cable	X	X
Warning Display Amplifier	X	X
Steering Column Harness Lock	X	X
Lighting Control Switch	X	X
Cargo Lamp Switch	X	X
Headlamp Dimmer Switch	X	X
Headlamp Dimmer Switch	X	X
Relay Glass Hatch / Back Door	X	X
Relay - Headlamp	X	X
Relay - Tail Gate Release	X	X
Headlamp Relay	X	X
Rear Defrost Relay	X	X
Horn Relay	X	X
Headlamp Panel Switch	X	X
Ignition Relay	X	X
Inhibitor Relay	X	X
Hold Relay	X	X
Hold Relay - Exhaust Gas